Control Commands

Model No. PT-MZ770
PT-SMZ77C
PT-MW730
PT-SMW73C
PT-MZ670
PT-MZ570
PT-SMZ66C
PT-MW630
PT-MW530

・Please refer to the Operating Instructions for the serial command format, limitations, connectionand other details.

・シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルの取扱説明書をご覧ください。

・有关串行控制命令的格式、限制事項、连接方法以及其他详情、请参阅各机型的使用说明书。

Panasonic

Rev.-2 (2021-05)

CONTROL COMMANDS

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
BASIC OPERATION REMOTE CONTROL	POWER	ON		PON	QPW	001	✓	✓	✓	✓
		OFF (STANDBY)		POF		000	✓	✓	✓	✓
	VOLUME	UP		AUU			✓	✓	✓	✓
		DOWN		AUD			✓	✓	✓	✓
	INPUT SELECT	COMPUTER1		IIS:RG1	QIN	RG1	✓	✓	✓	✓
		COMPUTER2		IIS:RG2		RG2	✓	✓	✓	✓
		VIDEO		IIS:VID		VID	✓	✓	✓	✓
		HDMI1		IIS:HD1		HD1	✓	✓	✓	✓
		HDMI2		IIS:HD2		HD2	✓	✓	✓	✓
		NETWORK/USB		IIS:NWP		NWP	✓	✓	✓	✓
		Panasonic APPLICATION		IIS:PA1		PA1	✓	✓	✓	✓
		Miracast/Mirroring		IIS:MC1		MC1	✓	✓	✓	✓
		MEMORY VIEWER		IIS:MV1		MV1	✓	✓	✓	✓
		DIGITAL LINK		IIS:DL1		DL1	✓	✓	✓	✓
	INPUT SELECT (DIGITAL LINK)	COMPUTER1		IIS:DL1:PC1	QIN	DL1:PC1	✓	✓	✓	✓
		COMPUTER2		IIS:DL1:PC2		DL1:PC2	✓	✓	✓	✓
		VIDEO		IIS:DL1:VID		DL1:VID	✓	✓	✓	✓
		HDMI1		IIS:DL1:HD1		DL1:HD1	✓	✓	✓	✓
		HDMI2		IIS:DL1:HD2		DL1:HD2	✓	✓	✓	✓
		S-VIDEO		IIS:DL1:SVD		DL1:SVD	✓	✓	✓	✓
	FREEZE	OFF		OFZ:0	QFZ	0	✓	✓	✓	✓
		ON		OFZ:1		1	✓	✓	✓	✓
	MENU KEY			OMN			✓	✓	✓	✓
	RETURN KEY			OBK			✓	✓	✓	✓
	ENTER KEY			OEN			✓	✓	✓	✓
	UP KEY			OCU			✓	✓	✓	✓
	DOWN KEY			OCD			✓	✓	✓	✓
	LEFT KEY			OCL			✓	✓	✓	✓
	RIGHT KEY			OCR			✓	✓	✓	✓
	DEFAULT KEY			OST			✓	✓	✓	✓
	AUTO SETUP KEY			OAS			✓	✓	✓	✓
	SHUTTER	OFF		OSH:0	QSH	0	✓	✓	✓	✓
		ON		OSH:1		1	✓	✓	✓	✓
	SHUTTER(Toggle)	OFF		OSH	QSH	0	✓	✓	✓	✓
		ON				1	✓	✓	✓	✓
	DIGITAL ZOOM UP			DZU			✓	✓	✓	✓
	DIGITAL ZOOM DOWN			DZD			✓	✓	✓	✓
	FUNCTION KEY			FC1			✓	✓	✓	✓
	SYSTEM SELCTOR KEY			OSL			✓	✓	✓	✓
	ASPECT KEY			VS1			✓	✓	✓	✓
	ECO			OEC			✓	✓	✓	✓
	NUMERIC KEY	0		ONK:0			✓	✓	✓	✓
		1		ONK:1			✓	✓	✓	✓
		2		ONK:2			✓	✓	✓	✓
		3		ONK:3			✓	✓	✓	✓
		4		ONK:4			✓	✓	✓	✓
		5		ONK:5			✓	✓	✓	✓
		6		ONK:6			✓	✓	✓	✓
		7		ONK:7			✓	✓	✓	✓
		8		ONK:8			✓	✓	✓	✓
		9		ONK:9			✓	✓	✓	✓
	LENS HOME POSITION	EXECUTE		VXX:LNSI1=+00001			✓	✓	✓	✓
	LENS SHIFT-HORIZONTAL	SLOW+		VXX:LNSI2=+00000			✓	✓	✓	✓
		SLOW-		VXX:LNSI2=+00001			✓	✓	✓	✓
		NORMAL+		VXX:LNSI2=+00100			✓	✓	✓	✓
		NORMAL-		VXX:LNSI2=+00101			✓	✓	✓	✓
		FAST+		VXX:LNSI2=+00200			✓	✓	✓	✓
		FAST-		VXX:LNSI2=+00201			✓	✓	✓	✓
	LENS SHIFT-VERTICAL	SLOW+		VXX:LNSI3=+00000			✓	✓	✓	✓
		SLOW-		VXX:LNSI3=+00001			✓	✓	✓	✓
		NORMAL+		VXX:LNSI3=+00100			✓	✓	✓	✓
		NORMAL-		VXX:LNSI3=+00101			✓	✓	✓	✓
		FAST+		VXX:LNSI3=+00200			✓	✓	✓	✓
		FAST-		VXX:LNSI3=+00201			✓	✓	✓	✓
	LENS FOCUS	SLOW+		VXX:LNSI4=+00000			✓	✓	✓	✓
		SLOW-		VXX:LNSI4=+00001			✓	✓	✓	✓
		NORMAL+		VXX:LNSI4=+00100			✓	✓	✓	✓
		NORMAL-		VXX:LNSI4=+00101			✓	✓	✓	✓
		FAST+		VXX:LNSI4=+00200			✓	✓	✓	✓
		FAST-		VXX:LNSI4=+00201			✓	✓	✓	✓
	LENS ZOOM	SLOW+		VXX:LNSI5=+00000			✓	✓	✓	✓
		SLOW-		VXX:LNSI5=+00001			✓	✓	✓	✓
		NORMAL+		VXX:LNSI5=+00100			✓	✓	✓	✓
		NORMAL-		VXX:LNSI5=+00101			✓	✓	✓	✓
		FAST+		VXX:LNSI5=+00200			✓	✓	✓	✓
		FAST-		VXX:LNSI5=+00201			✓	✓	✓	✓
	STATUS KEY			STS			✓	✓	✓	✓
	LENS FOCUS KEY			OLF			✓	✓	✓	✓
	LENS SHIFT KEY			OLH			✓	✓	✓	✓
	LENS ZOOM KEY			OLZ			✓	✓	✓	✓
	DIGITAL LINK KEY			DLK			✓	✓	✓	✓
	INPUT MENU KEY			IPT			✓	✓	✓	✓
	P-TIMER			PTM			✓	✓	✓	✓
	SCREEN ADJUSTMENT			OSA			✓	✓	✓	✓
	AUDIO MUTE	OFF		AMT:0	QMT	0	✓	✓	✓	✓
		ON		AMT:1		1	✓	✓	✓	✓
	SELF DIAGNOSIS				QVX:ERRS1	ERRS1=*****……	✓	✓	✓	✓
PICTURE	PICTURE MODE	DYNAMIC		VPM:DYN	QPM	DYN	✓	✓	✓	✓
		NATURAL		VPM:NAT		NAT	✓	✓	✓	✓
		STANDARD		VPM:STD		STD	✓	✓	✓	✓
		BLACK BOARD		VPM:BBD		BBD	✓	✓	✓	✓
		WHITE BOARD		VPM:WBD		WBD	✓	✓	✓	✓
		CINEMA		VPM:CIN		CIN	✓	✓	✓	✓
		DICOM SIM.		VPM:DIC		DIC	✓	✓	✓	✓
	CONTRAST	-31		VCN:-31	QVR	-31	✓	✓	✓	✓
		+31		VCN:031		031	✓	✓	✓	✓
	BRIGHTNESS	-31		VBR:-31	QVB	-31	✓	✓	✓	✓
		+31		VBR:031		031	✓	✓	✓	✓
	COLOR	-31		VCO:-31	QVC	-31	✓	✓	✓	✓
		+31		VCO:031		031	✓	✓	✓	✓
	TINT	-31		VTN:-31	QVT	-31	✓	✓	✓	✓
		+31		VTN:031		031	✓	✓	✓	✓
	SHARPNESS	0		VSR:000	QVS	000	✓	✓	✓	✓
		15		VSR:015		015	✓	✓	✓	✓
	COLOR TEMPERATURE	LOW		OTE:0	QTE	0	✓	✓	✓	✓
		HIGH		OTE:2		2	✓	✓	✓	✓
		USER		OTE:4		4	✓	✓	✓	✓
		USER1(USER)		OTE:04		4	✓	✓	✓	✓
		DEFAULT		OTE:10		10	✓	✓	✓	✓
	COLOR TEMP-NAME SETTING USER1	*COLORTEMP1*		VXX:NCGS1=*COLORTEMP1*	QVX:NCGS1	NCGS1=*COLORTEMP1*	✓	✓	✓	✓
	COLOR TEMP-NAME SETTING USER2	*COLORTEMP2*		VXX:NCGS3=*COLORTEMP2*	QVX:NCGS3	NCGS3=*COLORTEMP2*	✓	✓	✓	✓
	COLOR TEMP-NAME CLEAR USER1	*COLORTEMP1*		VXX:NCLI1=+00000			✓	✓	✓	✓
	COLOR TEMP-NAME CLEAR USER2	*COLORTEMP2*		VXX:NCLI3=+00000			✓	✓	✓	✓
	WHITE BALANCE LOW-RED	-127		VOR:001	QOR	001	✓	✓	✓	✓
		+127		VOR:255		255	✓	✓	✓	✓
	WHITE BALANCE LOW-GREEN	-127		VOG:001	QOG	001	✓	✓	✓	✓
		+127		VOG:255		255	✓	✓	✓	✓
	WHITE BALANCE LOW-BLUE	-127		VOB:001	QOB	001	✓	✓	✓	✓
		+127		VOB:255		255	✓	✓	✓	✓
	WHITE BALANCE HIGH-RED	0		VHR:000	QHR	000	✓	✓	✓	✓
		+255		VHR:255		255	✓	✓	✓	✓
	WHITE BALANCE HIGH-GREEN	0		VHG:000	QHG	000	✓	✓	✓	✓
		+255		VHG:255		255	✓	✓	✓	✓
	WHITE BALANCE HIGH-BLUE	0		VHB:000	QHB	000	✓	✓	✓	✓
		+255		VHB:255		255	✓	✓	✓	✓
	GAMMA(PRESET)	-8		VXX:GAMI1=-00008	QVX:GAMI1	GAMI1=-00008	✓	✓	✓	✓
		+7		VXX:GAMI1=+00007		GAMI1=+00007	✓	✓	✓	✓
	DAYLIGHT VIEW	OFF		VXX:DLVI0=+00000	QVX:DLVI0	DLVI0=+00000	✓	✓	✓	✓
		AUTO		VXX:DLVI0=+00001		DLVI0=+00001	✓	✓	✓	✓
		1		VXX:DLVI0=+00002		DLVI0=+00002	✓	✓	✓	✓
		2		VXX:DLVI0=+00003		DLVI0=+00003	✓	✓	✓	✓
		3		VXX:DLVI0=+00004		DLVI0=+00004	✓	✓	✓	✓
	NOISE REDUCTION	OFF		VNS:0	QNS	0	✓	✓	✓	✓
		1		VNS:1		1	✓	✓	✓	✓
		2		VNS:2		2	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
		3		VNS:3		3	✓	✓	✓	✓
	DYNAMIC CONTRAST/IRIS	OFF		OAI:0	QAI	0	✓	✓	✓	✓
		1		OAI:1		1	✓	✓	✓	✓
		2		OAI:2		2	✓	✓	✓	✓
		USER		OAI:4		4	✓	✓		
	DYNAMIC CONTRAST (LIGHTS OUT TIMER)	DISABLE		VXX:DYCS2=OFF	QVX:DYCS2	OFF	✓	✓		
		0.0s		VXX:DYCS2=0.0		0.0	✓	✓		
		10.0s		VXX:DYCS2=10.0		10.0	✓	✓		
	DYNAMIC CONTRAST (LIGHTS OUT SIGNAL LEVEL)	0		VXX:DYCI3=+00000	QVX:DYCI3	00000	✓	✓		
		5		VXX:DYCI3=+00005		00005	✓	✓		
	TV-SYSTEM	AUTO1		VSG:AT1	QSG	AT1	✓	✓	✓	✓
		AUTO2		VSG:AT2		AT2	✓	✓	✓	✓
		NTSC		VSG:NTS		NTS	✓	✓	✓	✓
		NTSC4.43		VSG:N44		N44	✓	✓	✓	✓
		PAL		VSG:PAL		PAL	✓	✓	✓	✓
		PAL-M		VSG:PAM		PAM	✓	✓	✓	✓
		PAL-N		VSG:PAN		PAN	✓	✓	✓	✓
		PAL60		VSG:P60		P60	✓	✓	✓	✓
		SECAM		VSG:SEC		SEC	✓	✓	✓	✓
	SYSTEM SELECTOR RGB(VGA/480P)	VGA60		ORF:0	QRF	0	✓	✓	✓	✓
		480P(YCbCr)		ORF:1		1	✓	✓	✓	✓
		480p(RGB)		ORF:3		3	✓	✓	✓	✓
	SYSTEM SELECTOR RGB(Other)/DVI/SLOT-DVI	RGB		ORF:0	QRF	0	✓	✓	✓	✓
		YPbPr		ORF:1		1	✓	✓	✓	✓
	SYSTEM SELECTOR HDMI/DIGITAL LINK/SLOT-HDMI	RGB		ORF:0	QRF	0	✓	✓	✓	✓
		YPbPr		ORF:1		1	✓	✓	✓	✓
		AUTO		ORF:2		2	✓	✓	✓	✓
	REAL TIME KEYSTONE	OFF		OAK:0	QAK	0	✓	✓	✓	✓
		ON		OAK:1		1	✓	✓	✓	✓
	GEOMETRY	OFF		VXX:GMMI0=+00000	QVX:GMMI0	GMMI0=+00000	✓	✓	✓	✓
		KEYSTONE		VXX:GMMI0=+00001		GMMI0=+00001	✓	✓	✓	✓
		CURVED		VXX:GMMI0=+00002		GMMI0=+00002	✓	✓	✓	✓
		CORNER-CORRECTION		VXX:GMMI0=+00010		GMMI0=+00010	✓	✓	✓	✓
	GEOMETRY-KEYSTONE- LENS THROW RATIO	0.7	0.1 step	VXX:GMKS0=+00.7	QVX:GMKS0	GMKS0=+00.7	+00.5	+00.5	+00.5	+00.5
		16.5		VXX:GMKS0=+16.5		GMKS0=+16.5	+10.5	+10.5	+10.5	+10.5
	GEOMETRY-KEYSTONE- VERTICAL BALANCE	-60		VXX:GMKI4=-00060	QVX:GMKI4	GMKI4=-00060	✓	✓	✓	✓
		+60		VXX:GMKI4=+00060		GMKI4=+00060	✓	✓	✓	✓
	GEOMETRY-KEYSTONE- HORIZONTAL BALANCE	-30		VXX:GMKI7=-00030	QVX:GMKI7	GMKI7=-00030	✓	✓	✓	✓
		+30		VXX:GMKI7=+00030		GMKI7=+00030	✓	✓	✓	✓
	GEOMETRY-KEYSTONE- VERTICAL KEYSTONE	-40.0 (-45.0)*	0.2 step	VXX:GMKS8=-40.0	QVX:GMKS8	GMKS8=-40.0	-25.0(0.5step)	-35.0(0.5step)	-25.0(0.5step)	-35.0(0.5step)
		+40.0 (+45.0)*		VXX:GMKS8=+40.0		GMKS8=+40.0	+25.0(0.5step)	+35.0(0.5step)	+25.0(0.5step)	+35.0(0.5step)
	GEOMETRY-KEYSTONE- HORIZONTAL KEYSTONE	-15.0 (-40.0)*	0.2 step	VXX:GMKS9=-15.0	QVX:GMKS9	GMKS9=-15.0	-30.0(0.5step)	-35.0(0.5step)	-30.0(0.5step)	-35.0(0.5step)
		+15.0 (+40.0)*		VXX:GMKS9=+15.0		GMKS9=+15.0	+30.0(0.5step)	+35.0(0.5step)	+30.0(0.5step)	+35.0(0.5step)
	GEOMETRY-CURVED-LENS THROW RATIO	0.7	0.1 step	VXX:GMCS0=+00.7	QVX:GMCS0	GMCS0=+00.7	+00.5	+00.5	+00.5	+00.5
		16.5		VXX:GMCS0=+16.5		GMCS0=+16.5	+10.5	+10.5	+10.5	+10.5
	GEOMETRY-CURVED- VERTICAL ARC	-50 (-100)*		VXX:GMCI3=-00050	QVX:GMCI3	GMCI3=-00050	✓	✓	✓	✓
		+50 (+100)*		VXX:GMCI3=+00050		GMCI3=+00050	✓	✓	✓	✓
	GEOMETRY-CURVED- HORIZONTAL ARC	-50 (-100)*		VXX:GMCI7=-00050	QVX:GMCI7	GMCI7=-00050	✓	✓	✓	✓
		+50 (+100)*		VXX:GMCI7=+00050		GMCI7=+00050	✓	✓	✓	✓
	GEOMETRY-CURVED- VERTICAL BALANCE	-60		VXX:GMCI2=-00060	QVX:GMCI2	GMCI2=-00060	✓	✓	✓	✓
		+60		VXX:GMCI2=+00060		GMCI2=+00060	✓	✓	✓	✓
	GEOMETRY-CURVED- HORIZONTAL BALANCE	-30		VXX:GMCI6=-00030	QVX:GMCI6	GMCI6=-00030	✓	✓	✓	✓
		+30		VXX:GMCI6=+00030		GMCI6=+00030	✓	✓	✓	✓
	GEOMETRY-CURVED- VERTICAL KEYSTONE	-40.0 (-45.0)*	0.2 step	VXX:GMCS8=-40.0	QVX:GMCS8	GMCS8=-40.0	-25.0(0.5step)	-35.0(0.5step)	-25.0(0.5step)	-35.0(0.5step)
		+40.0 (+45.0)*		VXX:GMCS8=+40.0		GMCS8=+40.0	+25.0(0.5step)	+35.0(0.5step)	+25.0(0.5step)	+35.0(0.5step)
	GEOMETRY-CURVED- HORIZONTAL KEYSTONE	-15.0 (-40.0)*	0.2 step	VXX:GMCS9=-15.0	QVX:GMCS9	GMCS9=-15.0	-30.0(0.5step)	-35.0(0.5step)	-30.0(0.5step)	-35.0(0.5step)
		+15.0 (+40.0)*		VXX:GMCS9=+15.0		GMCS9=+15.0	+30.0(0.5step)	+35.0(0.5step)	+30.0(0.5step)	+35.0(0.5step)
	GEOMETRY-CURVED- MAINTAIN ASPECT RATIO	OFF		VXX:GMCIA=+00000	QVX:GMCIA	GMCIA=+00000	✓	✓	✓	✓
		ON		VXX:GMCIA=+00001		GMCIA=+00001	✓	✓	✓	✓
	GEOMETRY-CORNER CORRECTION-UPPER LEFT(V)	*min.*		VXX:GMFI1=+00000	QVX:GMFI1	GMFI1=+00000	0	0	0	0
		max.		VXX:GMFI1=+00300		GMFI1=+00300	+300	+200	+300	+200
	GEOMETRY-CORNER CORRECTION-UPPER RIGHT(V)	*min.*		VXX:GMFI2=+00000	QVX:GMFI2	GMFI2=+00000	0	0	0	0
		max.		VXX:GMFI2=+00300		GMFI2=+00300	+300	+200	+300	+200
	GEOMETRY-CORNER CORRECTION-LOWER LEFT(V)	*min.*		VXX:GMFI3=-00300	QVX:GMFI3	GMFI3=-00300	-300	-200	-300	-200
		max.		VXX:GMFI3=+00000		GMFI3=+00000	0	0	0	0
POSITION	GEOMETRY-CORNER CORRECTION-LOWER RIGHT(V)	*min.*		VXX:GMFI4=-00300	QVX:GMFI4	GMFI4=-00300	-300	-200	-300	-200
		max.		VXX:GMFI4=+00000		GMFI4=+00000	0	0	0	0
	GEOMETRY-CORNER CORRECTION-LINEARITY(V)	*min.*		VXX:GMFI5=-00127	QVX:GMFI5	GMFI5=-00127	-127	-127	-127	-127
		max.		VXX:GMFI5=+00127		GMFI5=+00127	+127	+127	+127	+127
	GEOMETRY-CORNER CORRECTION-UPPER LEFT(H)	*min.*		VXX:GMFI6=+00000	QVX:GMFI6	GMFI6=+00000	0	0	0	0
		max.		VXX:GMFI6=+00480		GMFI6=+00480	+480	+320	+480	+320
	GEOMETRY-CORNER CORRECTION-UPPER RIGHT(H)	*min.*		VXX:GMFI7=-00480	QVX:GMFI7	GMFI7=-00480	-480	-320	-480	-320
		max.		VXX:GMFI7=+00000		GMFI7=+00000	0	0	0	0
	GEOMETRY-CORNER CORRECTION-LOWER LEFT(H)	*min.*		VXX:GMFI8=+00000	QVX:GMFI8	GMFI8=+00000	0	0	0	0
		max.		VXX:GMFI8=+00480		GMFI8=+00480	+480	320	+480	320
	GEOMETRY-CORNER CORRECTION-LOWER RIGHT(H)	*min.*		VXX:GMFI9=-00480	QVX:GMFI9	GMFI9=-00480	-480	-320	-480	-320
		max.		VXX:GMFI9=+00000		GMFI9=+00000	0	0	0	0
	GEOMETRY-CORNER CORRECTION-LINEARITY(H)	*min.*		VXX:GMFIA=-00127	QVX:GMFIA	GMFIA=-00127	-127	-127	-127	-127
		max.		VXX:GMFIA=+00127		GMFIA=+00127	+127	+127	+127	+127
	SHIFT-HORIZONTAL	0		VTH:0000	QTH	0000	✓	✓	✓	✓
		+4095		VTH:4095		4095	✓	✓	✓	✓
	SHIFT-VERTICAL	0		VTV:0000	QTV	0000	✓	✓	✓	✓
		+4094		VTV:4094		4094	✓	✓	✓	✓
	CLOCK PHASE	0		VCP:000	QCP	000	✓	✓	✓	✓
		+31		VCP:031		063	✓	✓	✓	✓
	ASPECT	AUTO/VID AUTO/DEFAULT		VSE:0	QSE	0	✓	✓	✓	✓
		NORMAL(4:3)		VSE:1		1	✓	✓	✓	✓
		WIDE(16:9)		VSE:2		2	✓	✓	✓	✓
		NATIVE(through)		VSE:5		5	✓	✓	✓	✓
		FULL(HV FIT)		VSE:6		6	✓	✓	✓	✓
		H-FIT		VSE:9		9	✓	✓	✓	✓
		V-FIT		VSE:10		10	✓	✓	✓	✓
	ZOOM-HORIZONTAL	50		OZH:050	QZH	050	✓	✓	✓	✓
		999		OZH:999		999	✓	✓	✓	✓
	ZOOM-VERTICAL	50		OZV:050	QZV	050	✓	✓	✓	✓
		999		OZV:999		999	✓	✓	✓	✓
	ZOOM-BOTH	50		OZO:050	QZO	050	✓	✓	✓	✓
		999		OZO:999		999	✓	✓	✓	✓
	ZOOM-INTERLOCKED	OFF		OZS:0	QZS	0	✓	✓	✓	✓
		ON		OZS:1		1	✓	✓	✓	✓
	ZOOM-MODE	INTERNAL		OZT:0	QZT	0	✓	✓	✓	✓
		FULL		OZT:1		1	✓	✓	✓	✓
	FRAME LOCK	OFF		VFL:0	QFL	0	✓	✓	✓	✓
		ON		VFL:1		1	✓	✓	✓	✓
	DIGITAL CINEMA REALITY	AUTO		OPD:0	QPD	0	✓	✓	✓	✓
		OFF		OPD:1		1	✓	✓	✓	✓
		30p/25p FIXED		OPD:2		2	✓	✓	✓	✓
	BLANKING-UPPER	*min.*		DBU:000	QLU	000	0	0	0	0
		max.		DBU:2398		2398	599	599	599	599
	BLANKING-LOWER	*min.*		DBB:000	QLB	000	0	0	0	0
		max.		DBB:2398		2398	599	599	599	599
	BLANKING-RIGHT	*min.*		DBR:000	QLR	000	0	0	0	0
		max.		DBR:3838		3838	959	959	959	959
	BLANKING-LEFT	*min.*		DBL:000	QLL	000	0	0	0	0
		max.		DBL:3838		3838	959	959	959	959
ADVANCED	INPUT RESOLUTION- TOTAL DOTS	330		VTD:0330	QTD	0330	✓	✓	✓	✓
		4095		VTD:4095		4095	✓	✓	✓	✓
	INPUT RESOLUTION- DISPLAY DOTS	300		VDD:0300	QDD	0300	✓	✓	✓	✓
		4065		VDD:4065		4065	✓	✓	✓	✓
	INPUT RESOLUTION- TOTAL LINES	155		VTL:0155	QTL	0155	✓	✓	✓	✓
		2047		VTL:2047		2047	✓	✓	✓	✓
	INPUT RESOLUTION- DISPLAY LINES	150		VDL:0150	QDL	0150	✓	✓	✓	✓
		2037		VDL:2037		2037	✓	✓	✓	✓
	CLAMP POSITION	1		VLT:001	QLT	001	✓	✓	✓	✓
		255		VLT:255		255	✓	✓	✓	✓
	RASTER POSITION-HORIZONTAL	-2048		VRH:2952	QRH	2952	✓	✓	✓	✓
		+2047		VRH:7047		7047	✓	✓	✓	✓
	RASTER POSITION-VERTICAL	-2048		VRV:2952	QRV	2952	✓	✓	✓	✓
		+2047		VRV:7047		7047	✓	✓	✓	✓
	LANGUAGE	English		OLG:ENG	QLG	ENG	✓	✓	✓	✓
		German		OLG:DEU		DEU	✓	✓	✓	✓
		French		OLG:FRA		FRA	✓	✓	✓	✓
		Spanish		OLG:ESP		ESP	✓	✓	✓	✓
		Italian		OLG:ITL		ITL	✓	✓	✓	✓
		Japanese		OLG:JPN		JPN	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
DISPLAY LANGUAGE		Chinese		OLG:CHI		CHI	✓	✓	✓	✓
		Russian		OLG:RUS		RUS	✓	✓	✓	✓
		Korea		OLG:KOR		KOR	✓	✓	✓	✓
		Portuguse		OLG:POR		POR	✓	✓	✓	✓
		Swedish		OLG:SVE		SVE	✓	✓	✓	✓
		Norwegan		OLG:NOR		NOR	✓	✓	✓	✓
		Danish		OLG:DAN		DAN	✓	✓	✓	✓
		Polish		OLG:POL		POL	✓	✓	✓	✓
		Czech		OLG:CES		CES	✓	✓	✓	✓
		Hungarian		OLG:MAG		MAG	✓	✓	✓	✓
		Thai		OLG:THA		THA	✓	✓	✓	✓
		Dutch		OLG:NLD		NLD	✓	✓	✓	✓
		Finnish		OLG:FIN		FIN	✓	✓	✓	✓
		Romanian		OLG:RUM		RUM	✓	✓	✓	✓
		Turkish		OLG:TUR		TUR	✓	✓	✓	✓
		Arabic		OLG:ARA		ARA	✓	✓	✓	✓
		Kazakh		OLG:KAZ		KAZ	✓	✓	✓	✓
		Vietnamese		OLG:VIE		VIE	✓	✓	✓	✓
	COLOR MATCHING	OFF		VXX:CMAI0=+00000	QVX:CMAI0	CMAI0=+00000	✓	✓	✓	✓
		3COLORS		VXX:CMAI0=+00001		CMAI0=+00001	✓	✓	✓	✓
		7COLORS		VXX:CMAI0=+00002		CMAI0=+00002	✓	✓	✓	✓
	COLOR MATCHING-3COLORS-RED	0 (R,G,B)		VMR:0000,0000,0000	QMR	0000,0000,0000	✓	✓	✓	✓
		2048,2048,2048(R,G,B)		VMR:2048,2048,2048		2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-3COLORS-GREEI	0 (R,G,B)		VMG:0000,0000,0000	QMG	0000,0000,0000	✓	✓	✓	✓
		2048,2048,2048(R,G,B)		VMG:2048,2048,2048		2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-3COLORS-BLUE	0 (R,G,B)		VMB:0000,0000,0000	QMB	0000,0000,0000	✓	✓	✓	✓
		2048,2048,2048(R,G,B)		VMB:2048,2048,2048		2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-3COLORS-WHIT	256 (GAIN)		VMW:0256	QMW	0256	✓	✓	✓	✓
		2048(GAIN)		VMW:2048		2048	✓	✓	✓	✓
	COLOR MATCHING-3COLORS-AUTO TESTPATTERN	OFF		VXX:CATI0=+00000	QVX:CATI0	CATI0=+00000	✓	✓	✓	✓
		ON		VXX:CATI0=+00001		CATI0=+00001	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-RED	0 (R,G,B)		VXX:C7CS0=0000,0000,0000	QVX:C7CS0	C7CS0=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS0=2048,2048,2048		C7CS0=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-GREEI	0 (R,G,B)		VXX:C7CS1=0000,0000,0000	QVX:C7CS1	C7CS1=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS1=2048,2048,2048		C7CS1=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-BLUE	0 (R,G,B)		VXX:C7CS2=0000,0000,0000	QVX:C7CS2	C7CS2=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS2=2048,2048,2048		C7CS2=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-CYAN	0 (R,G,B)		VXX:C7CS3=0000,0000,0000	QVX:C7CS3	C7CS3=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS3=2048,2048,2048		C7CS3=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-MAGE	0 (R,G,B)		VXX:C7CS4=0000,0000,0000	QVX:C7CS4	C7CS4=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS4=2048,2048,2048		C7CS4=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-YELLO	0 (R,G,B)		VXX:C7CS5=0000,0000,0000	QVX:C7CS5	C7CS5=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS5=2048,2048,2048		C7CS5=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-WHIT	0 (R,G,B)		VXX:C7CS6=0000,0000,0000	QVX:C7CS6	C7CS6=0000,0000,0000	✓	✓	✓	✓
		2048(R,G,B)		VXX:C7CS6=2048,2048,2048		C7CS6=2048,2048,2048	✓	✓	✓	✓
	COLOR MATCHING-7COLORS-AUTO TESTPATTERN	OFF		VXX:CATI1=+00000	QVX:CATI1	CATI1=+00000	✓	✓	✓	✓
		ON		VXX:CATI1=+00001		CATI1=+00001	✓	✓	✓	✓
	COLOR CORRECTION	OFF		VCM:0	QMC	0	✓	✓	✓	✓
		USER		VCM:1		1	✓	✓	✓	✓
	COLOR CORRECTION-RED	-30		VXX:CCRI0=-00030	QVX:CCRI0	CCRI0=-00030	✓	✓	✓	✓
		+30		VXX:CCRI0=+00030		CCRI0=+00030	✓	✓	✓	✓
	COLOR CORRECTION-GREEN	-30		VXX:CCRI1=-00030	QVX:CCRI1	CCRI1=-00030	✓	✓	✓	✓
		+30		VXX:CCRI1=+00030		CCRI1=+00030	✓	✓	✓	✓
	COLOR CORRECTION-BLUE	-30		VXX:CCRI2=-00030	QVX:CCRI2	CCRI2=-00030	✓	✓	✓	✓
		+30		VXX:CCRI2=+00030		CCRI2=+00030	✓	✓	✓	✓
	COLOR CORRECTION-CYAN	-30		VXX:CCRI3=-00030	QVX:CCRI3	CCRI3=-00030	✓	✓	✓	✓
		+30		VXX:CCRI3=+00030		CCRI3=+00030	✓	✓	✓	✓
	COLOR CORRECTION-MAGENTA	-30		VXX:CCRI4=-00030	QVX:CCRI4	CCRI4=-00030	✓	✓	✓	✓
		+30		VXX:CCRI4=+00030		CCRI4=+00030	✓	✓	✓	✓
	COLOR CORRECTION-YELLOW	-30		VXX:CCRI5=-00030	QVX:CCRI5	CCRI5=-00030	✓	✓	✓	✓
		+30		VXX:CCRI5=+00030		CCRI5=+00030	✓	✓	✓	✓
	AUTO SIGNAL	OFF		VXX:AASI0=+00000	QVX:AASI0	AASI0=+00000	✓	✓	✓	✓
		ON		VXX:AASI0=+00001		AASI0=+00001	✓	✓	✓	✓
	AUTO SETUP -MODE	USER		OAM:0	QAM	0	✓	✓	✓	✓
		DEFAULT		OAM:1		1	✓	✓	✓	✓
		WIDE		OAM:2		2	✓	✓	✓	✓
	AUTO SETUP -POSITION ADJ.	OFF		VXX:APAI0=+00000	QVX:APAI0	APAI0=+00000	✓	✓	✓	✓
		ON		VXX:APAI0=+00001		APAI0=+00001	✓	✓	✓	✓
	RGB IN-RGB1 SYNC SLICE LEVEL	LOW		VXX:STRI0=+00000	QVX:STRI0	STRI0=+00000	✓	✓	✓	✓
		HIGH		VXX:STRI0=+00001		STRI0=+00001	✓	✓	✓	✓
	RGB IN-RGB2 SYNC SLICE LEVEL	LOW		VXX:STRI1=+00000	QVX:STRI1	STRI1=+00000	✓	✓	✓	✓
		HIGH		VXX:STRI1=+00001		STRI1=+00001	✓	✓	✓	✓
	RGB IN-RGB2 EDID MODE	DEFAULT		VXX:EDMI1=+00000	QVX:EDMI1	EDMI1=+00000	✓	✓	✓	✓
		SCREEB FIT		VXX:EDMI1=+00001		EDMI1=+00001	✓	✓	✓	✓
		USER		VXX:EDMI1=+00010		EDMI1=+00010	✓	✓	✓	✓
	RGB IN-RGB2 EDID RESOLUTION	1024x768p		VXX:EDRS1=1024:0768:p	QVX:EDRS1	EDRS1=1024:0768:p	✓	✓	✓	✓
		1280x720p		VXX:EDRS1=1280:0720:p		EDRS1=1280:0720:p	✓	✓	✓	✓
		1280x768p		VXX:EDRS1=1280:0768:p		EDRS1=1280:0768:p	✓	✓	✓	✓
		1280x800p		VXX:EDRS1=1280:0800:p		EDRS1=1280:0800:p	✓	✓	✓	✓
		1280x1024p		VXX:EDRS1=1280:1024:p		EDRS1=1280:1024:p	✓	✓	✓	✓
		1366x768p		VXX:EDRS1=1366:0768:p		EDRS1=1366:0768:p	✓	✓	✓	✓
		1400x1050p		VXX:EDRS1=1400:1050:p		EDRS1=1400:1050:p	✓	✓	✓	✓
		1440x900p		VXX:EDRS1=1440:0900:p		EDRS1=1440:0900:p	✓	✓	✓	✓
		1600x900p		VXX:EDRS1=1600:0900:p		EDRS1=1600:0900:p	✓	✓	✓	✓
		1600x1200p		VXX:EDRS1=1600:1200:p		EDRS1=1600:1200:p	✓	✓	✓	✓
		1680x1050p		VXX:EDRS1=1680:1050:p		EDRS1=1680:1050:p	✓	✓	✓	✓
		1920x1080p		VXX:EDRS1=1920:1080:p		EDRS1=1920:1080:p	✓	✓	✓	✓
		1920x1080i		VXX:EDRS1=1920:1080:i		EDRS1=1920:1080:i	✓	✓	✓	✓
		1920x1200p		VXX:EDRS1=1920:1200:p		EDRS1=1920:1200:p	✓	✓	✓	✓
	RGB IN-RGB2 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX:EDVI1=+06000	QVX:EDVI1	EDVI1=+06000	✓	✓	✓	✓
		50Hz		VXX:EDVI1=+05000		EDVI1=+05000	✓	✓	✓	✓
		48Hz		VXX:EDVI1=+04800		EDVI1=+04800	✓	✓	✓	✓
		30Hz		VXX:EDVI1=+03000		EDVI1=+03000	✓	✓	✓	✓
		25Hz		VXX:EDVI1=+02500		EDVI1=+02500	✓	✓	✓	✓
		24Hz		VXX:EDVI1=+02400		EDVI1=+02400	✓	✓	✓	✓
	HDMI IN-EDID MODE	DEFAULT		VXX:EDMI3=+00000	QVX:EDMI3	EDMI3=+00000	✓	✓	✓	✓
		SCREEN FIT		VXX:EDMI3=+00001		EDMI3=+00001	✓	✓	✓	✓
		USER		VXX:EDMI3=+00010		EDMI3=+00010	✓	✓	✓	✓
	HDMI IN-EDID RESOLUTION	1024x768p		VXX:EDRS3=1024:0768:p	QVX:EDRS3	EDRS3=1024:0768:p	✓	✓	✓	✓
		1280x720p		VXX:EDRS3=1280:0720:p		EDRS3=1280:0720:p	✓	✓	✓	✓
		1280x768p		VXX:EDRS3=1280:0768:p		EDRS3=1280:0768:p	✓	✓	✓	✓
		1280x800p		VXX:EDRS3=1280:0800:p		EDRS3=1280:0800:p	✓	✓	✓	✓
		1280x1024p		VXX:EDRS3=1280:1024:p		EDRS3=1280:1024:p	✓	✓	✓	✓
		1366x768p		VXX:EDRS3=1366:0768:p		EDRS3=1366:0768:p	✓	✓	✓	✓
		1400x1050p		VXX:EDRS3=1400:1050:p		EDRS3=1400:1050:p	✓	✓	✓	✓
		1440x900p		VXX:EDRS3=1440:0900:p		EDRS3=1440:0900:p	✓	✓	✓	✓
		1600x900p		VXX:EDRS3=1600:0900:p		EDRS3=1600:0900:p	✓	✓	✓	✓
		1600x1200p		VXX:EDRS3=1600:1200:p		EDRS3=1600:1200:p	✓	✓	✓	✓
		1680x1050p		VXX:EDRS3=1680:1050:p		EDRS3=1680:1050:p	✓	✓	✓	✓
		1920x1080p		VXX:EDRS3=1920:1080:p		EDRS3=1920:1080:p	✓	✓	✓	✓
		1920x1080i		VXX:EDRS3=1920:1080:i		EDRS3=1920:1080:i	✓	✓	✓	✓
		1920x1200p		VXX:EDRS3=1920:1200:p		EDRS3=1920:1200:p	✓	✓	✓	✓
	HDMI IN-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX:EDVI3=+06000	QVX:EDVI3	EDVI3=+06000	✓	✓	✓	✓
		50Hz		VXX:EDVI3=+05000		EDVI3=+05000	✓	✓	✓	✓
		48Hz		VXX:EDVI3=+04800		EDVI3=+04800	✓	✓	✓	✓
		30Hz		VXX:EDVI3=+03000		EDVI3=+03000	✓	✓	✓	✓
		25Hz		VXX:EDVI3=+02500		EDVI3=+02500	✓	✓	✓	✓
		24Hz		VXX:EDVI3=+02400		EDVI3=+02400	✓	✓	✓	✓
	HDMI IN-HDMI1 SIGNAL LEVEL	0-1023		VXX:HSLI1=+00000	QVX:HSLI1	HSLI1=+00000	✓	✓	✓	✓
		64-940		VXX:HSLI1=+00001		HSLI1=+00001	✓	✓	✓	✓
		AUTO		VXX:HSLI1=+00002		HSLI1=+00002	✓	✓	✓	✓
	HDMI IN-HDMI2 SIGNAL LEVEL	0-1023		VXX:HSLI2=+00000	QVX:HSLI2	HSLI2=+00000	✓	✓	✓	✓
		64-940		VXX:HSLI2=+00001		HSLI2=+00001	✓	✓	✓	✓
		AUTO		VXX:HSLI2=+00002		HSLI2=+00002	✓	✓	✓	✓
	HDMI IN-HDMI1 EDID SELECT	4K/60p		VXX:HESI1=+00000	QVX:HESI1	HESI1=+00000	✓			
		4K/30p		VXX:HESI1=+00001		HESI1=+00001	✓			
		2K		VXX:HESI1=+00002		HESI1=+00002	✓			
	HDMI IN-HDMI2 EDID SELECT	4K/60p		VXX:HESI2=+00000	QVX:HESI2	HESI2=+00000	✓			
		4K/30p		VXX:HESI2=+00001		HESI2=+00001	✓			
		2K		VXX:HESI2=+00002		HESI2=+00002	✓			
	HDMI IN-HDM2 EDID MODE	DEFAULT		VXX:EDMI6=+00000	QVX:EDMI6	EDMI6=+00000	✓	✓	✓	✓
		SCREEN FIT		VXX:EDMI6=+00001		EDMI6=+00001	✓	✓	✓	✓
		USER		VXX:EDMI6=+00010		EDMI6=+00010	✓	✓	✓	✓
	HDMI IN-HDMI2 EDID RESOLUTION	1024x768p		VXX:EDRS6=1024:0768:p	QVX:EDRS3	EDRS6=1024:0768:p	✓	✓	✓	✓
		1280x720p		VXX:EDRS6=1280:0720:p		EDRS6=1280:0720:p	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
DISPLAY OPTION		1280x768p		VXX:EDRS6=1280:0768:p		EDRS6=1280:0768:p	✓	✓	✓	✓
		1280x800p		VXX:EDRS6=1280:0800:p		EDRS6=1280:0800:p	✓	✓	✓	✓
		1280x1024p		VXX:EDRS6=1280:1024:p		EDRS6=1280:1024:p	✓	✓	✓	✓
		1366x768p		VXX:EDRS6=1366:0768:p		EDRS6=1366:0768:p	✓	✓	✓	✓
		1400x1050p		VXX:EDRS6=1400:1050:p		EDRS6=1400:1050:p	✓	✓	✓	✓
		1440x900p		VXX:EDRS6=1440:0900:p		EDRS6=1440:0900:p	✓	✓	✓	✓
		1600x900p		VXX:EDRS6=1600:0900:p		EDRS6=1600:0900:p	✓	✓	✓	✓
		1600x1200p		VXX:EDRS6=1600:1200:p		EDRS6=1600:1200:p	✓	✓	✓	✓
		1680x1050p		VXX:EDRS6=1680:1050:p		EDRS6=1680:1050:p	✓	✓	✓	✓
		1920x1080p		VXX:EDRS6=1920:1080:p		EDRS6=1920:1080:p	✓	✓	✓	✓
		1920x1080i		VXX:EDRS6=1920:1080:i		EDRS6=1920:1080:i	✓	✓	✓	✓
		1920x1200p		VXX:EDRS6=1920:1200:p		EDRS6=1920:1200:p	✓	✓	✓	✓
	HDMI IN-HDMI2 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX:EDVI6=+06000	QVX:EDVI6	EDVI6=+06000	✓	✓	✓	✓
		50Hz		VXX:EDVI6=+05000		EDVI6=+05000	✓	✓	✓	✓
		48Hz		VXX:EDVI6=+04800		EDVI6=+04800	✓	✓	✓	✓
		30Hz		VXX:EDVI6=+03000		EDVI6=+03000	✓	✓	✓	✓
		25Hz		VXX:EDVI6=+02500		EDVI6=+02500	✓	✓	✓	✓
		24Hz		VXX:EDVI6=+02400		EDVI6=+02400	✓	✓	✓	✓
	DIGITAL LINK-SIGNAL LEVEL	AUTO		VXX:DKLI1=+00000	QVX:DKLI1	DKLI1=+00000	✓	✓	✓	✓
		0-1023		VXX:DKLI1=+00001		DKLI1=+00001	✓	✓	✓	✓
		64-940		VXX:DKLI1=+00002		DKLI1=+00002	✓	✓	✓	✓
	DIGITAL LINK-EDID MODE	DEFAULT		VXX:EDMI4=+00000	QVX:EDMI4	EDMI4=+00000	✓	✓	✓	✓
		SCREEN FIT		VXX:EDMI4=+00001		EDMI4=+00001	✓	✓	✓	✓
		USER		VXX:EDMI4=+00010		EDMI4=+00010	✓	✓	✓	✓
	DIGITAL LINK-EDID RESOLUTION	1024x768p		VXX:EDRS4=1024:0768:p	QVX:EDRS4	EDRS4=1024:0768:p	✓	✓	✓	✓
		1280x720p		VXX:EDRS4=1280:0720:p		EDRS4=1280:0720:p	✓	✓	✓	✓
		1280x768p		VXX:EDRS4=1280:0768:p		EDRS4=1280:0768:p	✓	✓	✓	✓
		1280x800p		VXX:EDRS4=1280:0800:p		EDRS4=1280:0800:p	✓	✓	✓	✓
		1280x1024p		VXX:EDRS4=1280:1024:p		EDRS4=1280:1024:p	✓	✓	✓	✓
		1366x768p		VXX:EDRS4=1366:0768:p		EDRS4=1366:0768:p	✓	✓	✓	✓
		1400x1050p		VXX:EDRS4=1400:1050:p		EDRS4=1400:1050:p	✓	✓	✓	✓
		1440x900p		VXX:EDRS4=1440:0900:p		EDRS4=1440:0900:p	✓	✓	✓	✓
		1600x900p		VXX:EDRS4=1600:0900:p		EDRS4=1600:0900:p	✓	✓	✓	✓
		1600x1200p		VXX:EDRS4=1600:1200:p		EDRS4=1600:1200:p	✓	✓	✓	✓
		1680x1050p		VXX:EDRS4=1680:1050:p		EDRS4=1680:1050:p	✓	✓	✓	✓
		1920x1080p		VXX:EDRS4=1920:1080:p		EDRS4=1920:1080:p	✓	✓	✓	✓
		1920x1080i		VXX:EDRS4=1920:1080:i		EDRS4=1920:1080:i	✓	✓	✓	✓
		1920x1200p		VXX:EDRS4=1920:1200:p		EDRS4=1920:1200:p	✓	✓	✓	✓
	DIGITAL LINK-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX:EDVI4=+06000	QVX:EDVI4	EDVI4=+06000	✓	✓	✓	✓
		50Hz		VXX:EDVI4=+05000		EDVI4=+05000	✓	✓	✓	✓
		48Hz		VXX:EDVI4=+04800		EDVI4=+04800	✓	✓	✓	✓
		30Hz		VXX:EDVI4=+03000		EDVI4=+03000	✓	✓	✓	✓
		25Hz		VXX:EDVI4=+02500		EDVI4=+02500	✓	✓	✓	✓
		24Hz		VXX:EDVI4=+02400		EDVI4=+02400	✓	✓	✓	✓
	INPUT GUIDE	OFF		OID:0	QDI	0	✓	✓	✓	✓
		ON (SIMPLE)		OID:1		1	✓	✓	✓	✓
	OSD POSITION	UPPER LEFT		ODP:1	QDP	1	✓	✓	✓	✓
		CETRE LEFT		ODP:2		2	✓	✓	✓	✓
		LOWER LEFT		ODP:3		3	✓	✓	✓	✓
		TOP CENTER		ODP:4		4	✓	✓	✓	✓
		CENTER		ODP:5		5	✓	✓	✓	✓
		LOEER CENTER		ODP:6		6	✓	✓	✓	✓
		UPPER RIGHT		ODP:7		7	✓	✓	✓	✓
		CENTER RIGHT		ODP:8		8	✓	✓	✓	✓
		LOWER RIGHT		ODP:9		9	✓	✓	✓	✓
	OSD ROTATION	OFF		VXX:OSRI1=+00000	QVX:OSRI1	OSRI1=+00000	✓	✓	✓	✓
		CLOCKWISE		VXX:OSRI1=+00001		OSRI1=+00001	✓	✓	✓	✓
		COUNTER CLOCKWISE		VXX:OSRI1=+00002		OSRI1=+00002	✓	✓	✓	✓
	OSD MEMORY	OFF		VXX:OMYI0=+00000	QVX:OMYI0	OMYI0=+00000	✓	✓	✓	✓
		ON		VXX:OMYI0=+00001		OMYI0=+00001	✓	✓	✓	✓
	ON SCREEN	OFF		OOS:0	QOS	0	✓	✓	✓	✓
		ON		OOS:1		1	✓	✓	✓	✓
	OSD SIZE	NORMAL		VXX:OSZI1=+00100	QVX:OSZI1	OSZI1=+00100	✓		✓	
		DOUBLE		VXX:OSZI1=+00200		OSZI1=+00200	✓		✓	
	WARNING MESSAGE	OFF		VXX:WMDI0=+00000	QVX:WMDI0	WMDI0=+00000	✓	✓	✓	✓
		ON		VXX:WMDI0=+00001		WMDI0=+00001	✓	✓	✓	✓
	OSD DESIGN	1(YELLOW)		MOD:0	QOD	0	✓	✓	✓	✓
		2(BLUE)		MOD:1		1	✓	✓	✓	✓
		3(WHITE)		MOD:2		2	✓	✓	✓	✓
		4(GREEN)		MOD:3		3	✓	✓	✓	✓
		5(PEACH)		MOD:4		4	✓	✓	✓	✓
		6(BROWN)		MOD:5		5	✓	✓	✓	✓
	CLOSED CAPTION SETTING	OFF		OCC:0	QCC	0	✓	✓	✓	✓
		CC1		OCC:1		1	✓	✓	✓	✓
		CC2		OCC:2		2	✓	✓	✓	✓
		CC3		OCC:3		3	✓	✓	✓	✓
		CC4		OCC:4		4	✓	✓	✓	✓
	SCREEN SETTING	16:10		VSF:0	QSF	0	✓	✓	✓	✓
		16:9		VSF:1		1	✓	✓	✓	✓
		4:3		VSF:2		2	✓	✓	✓	✓
	SCREEN POSITION-VERTICAL	*min.*		VXX:VSPI0=-00120	QVX:VSPI0	VSPI0=-00120	-60	-40	-60	-40
		max.		VXX:VSPI0=+00120		VSPI0=+00120	60	40	60	40
	SCREEN POSITION-HOROZONTAL	*min.*		VXX:HSPI0=-00320	QVX:HSPI0	HSPI0=-00320	-160	-107	-160	-107
		max.		VXX:HSPI0=+00320		HSPI0=+00320	+160	+107	+160	+107
	STARTUP LOGO	OFF		MLO:0	QLO	0	✓	✓	✓	✓
		USER LOGO		MLO:1		1	✓	✓	✓	✓
		DEFAULT LOGO		MLO:2		2	✓	✓	✓	✓
	UNIFORMITY-WHITE/RED/GREEN/RED	* PARAMETER		E$W:*,****,****,**	E$R:*,**	**,****,****	✓	✓	✓	✓
		* PARAMETER 1	WHITE	E$W:W,****,****,**	E$R:W,**	**,****,****	✓	✓	✓	✓
			RED	E$W:R,****,****,**	E$R:R,**	**,****,****	✓	✓	✓	✓
			GREEN	E$W:G,****,****,**	E$R:G,**	**,****,****	✓	✓	✓	✓
			BLUE	E$W:B,****,****,**	E$R:B,**	**,****,****	✓	✓	✓	✓
		* PARAMETER 2	VERTICAL(-127)	E$W:*,-127,****,**	E$R:*,**	**,-127,****	✓	✓	✓	✓
			VERTICAL(+127)	E$W:*,+127,****,**	E$R:*,**	**,+127,****	✓	✓	✓	✓
		* PARAMETER 3	HORIZONTAL(-127)	E$W:*,****,-127,**	E$R:*,**	**,****,-127	✓	✓	✓	✓
			HOROZONTAL(+127)	E$W:*,****,+127,**	E$R:*,**	**,****,+127	✓	✓	✓	✓
		* PARAMETER 4	L1(OFF)	E$W:*,****,****,0*	E$R:*,0*	0*,****,****	✓	✓	✓	✓
			L1(ON)	E$W:*,****,****,1*	E$R:*,1*	1*,****,****	✓	✓	✓	✓
			L2(OFF)	E$W:*,****,****,*0	E$R:*,*0	*0,****,****	✓	✓	✓	✓
			L2(ON)	E$W:*,****,****,*1	E$R:*,*1	*1,****,****	✓	✓	✓	✓
	UNIFORMITY-WHITE/RED/GREEN/RED	* PARAMETER		E$W:*,****,****	E$R:*	**,****,****	✓	✓	✓	✓
		* PARAMETER 1	WHITE	E$W:W,****,****	E$R:W	**,****,****	✓	✓	✓	✓
			RED	E$W:R,****,****	E$R:R	**,****,****	✓	✓	✓	✓
			GREEN	E$W:G,****,****	E$R:G	**,****,****	✓	✓	✓	✓
			BLUE	E$W:B,****,****	E$R:B	**,****,****	✓	✓	✓	✓
		* PARAMETER 2	VERTICAL(-127)	E$W:*,-127,****		**,-127,****	✓	✓	✓	✓
			VERTICAL(+127)	E$W:*,+127,****		**,+127,****	✓	✓	✓	✓
		* PARAMETER 3	HORIZONTAL(-127)	E$W:*,****,-127		**,****,-127	✓	✓	✓	✓
			HOROZONTAL(+127)	E$W:*,****,+127		**,****,+127	✓	✓	✓	✓
		* PARAMETER 4	L1(OFF)			0*,****,****	✓	✓	✓	✓
			L1(ON)			1*,****,****	✓	✓	✓	✓
			L2(OFF)			*0,****,****	✓	✓	✓	✓
			L2(ON)			*1,****,****	✓	✓	✓	✓
	SHUTTER SETTING-FADE IN	0.0s(OFF)		VXX:SEFS1=0.0	QVX:SEFS1	SEFS1=0.0	✓	✓	✓	✓
		0.5s		VXX:SEFS1=0.5		SEFS1=0.5	✓	✓	✓	✓
		1.0s		VXX:SEFS1=1.0		SEFS1=1.0	✓	✓	✓	✓
		1.5s		VXX:SEFS1=1.5		SEFS1=1.5	✓	✓	✓	✓
		2.0s		VXX:SEFS1=2.0		SEFS1=2.0	✓	✓	✓	✓
		2.5s		VXX:SEFS1=2.5		SEFS1=2.5	✓	✓	✓	✓
		3.0s		VXX:SEFS1=3.0		SEFS1=3.0	✓	✓	✓	✓
		3.5s		VXX:SEFS1=3.5		SEFS1=3.5	✓	✓	✓	✓
		4.0s		VXX:SEFS1=4.0		SEFS1=4.0	✓	✓	✓	✓
		5.0s		VXX:SEFS1=5.0		SEFS1=5.0	✓	✓	✓	✓
		7.0s		VXX:SEFS1=7.0		SEFS1=7.0	✓	✓	✓	✓
		10.0s		VXX:SEFS1=10.0		SEFS1=10.0	✓	✓	✓	✓
	SHUTTER SETTING-FADE OUT	0.0s(OFF)		VXX:SEFS2=0.0	QVX:SEFS2	SEFS2=0.0	✓	✓	✓	✓
		0.5s		VXX:SEFS2=0.5		SEFS2=0.5	✓	✓	✓	✓
		1.0s		VXX:SEFS2=1.0		SEFS2=1.0	✓	✓	✓	✓
		1.5s		VXX:SEFS2=1.5		SEFS2=1.5	✓	✓	✓	✓
		2.0s		VXX:SEFS2=2.0		SEFS2=2.0	✓	✓	✓	✓
		2.5s		VXX:SEFS2=2.5		SEFS2=2.5	✓	✓	✓	✓
		3.0s		VXX:SEFS2=3.0		SEFS2=3.0	✓	✓	✓	✓
		3.5s		VXX:SEFS2=3.5		SEFS2=3.5	✓	✓	✓	✓
		4.0s		VXX:SEFS2=4.0		SEFS2=4.0	✓	✓	✓	✓
		5.0s		VXX:SEFS2=5.0		SEFS2=5.0	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
		7.0s		VXX:SEFS2=7.0		SEFS2=7.0	✓	✓	✓	✓
		10.0s		VXX:SEFS2=10.0		SEFS2=10.0	✓	✓	✓	✓
	SHUTTER SETTING-STARTUP	OPEN		VXX:SEFI3=+00000	QVX:SEFI3	SEFI3=+00000	✓	✓	✓	✓
		CLOSE		VXX:SEFI3=+00001		SEFI3=+00001	✓	✓	✓	✓
	SIGNAL SEARCH	OFF		OSR:0	QSR	0	✓	✓	✓	✓
		ON		OSR:1		1	✓	✓	✓	✓
	BACK COLOR	BLUE		OBC:0	QBC	0	✓	✓	✓	✓
		BLACK		OBC:1		1	✓	✓	✓	✓
		DEFAULT LOGO		OBC:2		2	✓	✓	✓	✓
		USER LOGO		OBC:3		3	✓	✓	✓	✓
	P-TIMER-MODE	COUNT DOWN		VXX:PTMI1=+00000	QVX:PTMI1	PTMI1=+00000	✓	✓	✓	✓
		COUNT UP		VXX:PTMI1=+00001		PTMI1=+00001	✓	✓	✓	✓
	P-TIMER-COUNT DOWN TIMER	1 MIN.		VXX:PTMI2=+00001	QVX:PTMI2	PTMI2=+00001	✓	✓	✓	✓
		180 MIN.		VXX:PTMI2=+00180		PTMI2=+00180	✓	✓	✓	✓
	P-TIMER-RESET	RESET		VXX:PTMI3=+00000			✓	✓	✓	✓
	P-TIMER-EXIT	EXIT		VXX:PTMI4=+00000			✓	✓	✓	✓
	STATUS			STS			✓	✓	✓	✓
	PROJECTOR ID	0(ALL)		RIS:00			✓	✓	✓	✓
		64		RIS:64			✓	✓	✓	✓
	PROJECTION METHOD INSTALLATION	FRONT/DESK		OIL:0	QSP	0	✓	✓	✓	✓
		REAR/DESK		OIL:1		1	✓	✓	✓	✓
		FRONT/CEILING		OIL:2		2	✓	✓	✓	✓
		REAR/CEILING		OIL:3		3	✓	✓	✓	✓
		FRONT/AUTO		OIL:4		4	✓	✓	✓	✓
		REAR/AUTO		OIL:5		5	✓	✓	✓	✓
	PROJECTION METHOD(AUTO)	FRONT/DESK			QVX:PJMI2	PJMI2=+00000	✓	✓	✓	✓
		REAR/DESK				PJMI2=+00001	✓	✓	✓	✓
		FRONT/CEILING				PJMI2=+00002	✓	✓	✓	✓
		REAR/CEILING				PJMI2=+00003	✓	✓	✓	✓
	AUTO COOLING CONDITION-STATUS	FLOOR			QVX:ADRI1	ADRI1=+00000	✓	✓	✓	✓
		CEILING				ADRI1=+00001	✓	✓	✓	✓
		VERTICAL UP				ADRI1=+00002	✓	✓	✓	✓
		VERTICAL DOWN				ADRI1=+00003	✓	✓	✓	✓
		PORTRAIT				ADRI1=+00004	✓	✓	✓	✓
	LIGHT POWER	NORMAL		VXX:LPWI1=+00000	QLP	LPWI1=+00000	✓	✓	✓	✓
		ECO		VXX:LPWI1=+00001		LPWI1=+00001	✓	✓	✓	✓
		QUIET		VXX:LPWI1=+00040		LPWI1=+00040	✓	✓	✓	✓
		USER		VXX:LPWI1=+00100		LPWI1=+00100	✓	✓		
	LIGHT OUTPUT	*min.*		VXX:LOPI2=+00050	QVX:LOPI2	LOPI2=+00050	30%	30%		
		max.		VXX:LOPI2=+01000		LOPI2=+01000	100%	100%		
	ECO MANAGEMENT-AMBIENT LIGHT DETECTION	OFF		VXX:ECOI1=+00000	QVX:ECOI1	ECOI1=+00000	✓	✓	✓	✓
		ON		VXX:ECOI1=+00001		ECOI1=+00001	✓	✓	✓	✓
	ECO MANAGEMENT-SIGNAL DETECTION	OFF		VXX:ECOI2=+00000	QVX:ECOI2	ECOI2=+00000	✓	✓	✓	✓
		ON		VXX:ECOI2=+00001		ECOI2=+00001	✓	✓	✓	✓
	POWER MANAGEMENT	OFF		VXX:ECOI5=+00000	QVX:ECOI5	ECOI5=+00000	✓	✓	✓	✓
		READY		VXX:ECOI5=+00001		ECOI5=+00001	✓	✓	✓	✓
		SHUTDOWN		VXX:ECOI5=+00002		ECOI5=+00002	✓	✓	✓	✓
	POWER MANAGEMENT-TIMER	5 MIN		VXX:ECOI6=+00005	QVX:ECOI6	ECOI6=+00005	✓	✓	✓	✓
		120 MIN		VXX:ECOI6=+00120		ECOI6=+00120	✓	✓	✓	✓
	STANDBY MODE	NORMAL		VXX:STMI0=+00000	QVX:STMI0	STMI0=+00000	✓	✓	✓	✓
		ECO		VXX:STMI0=+00003		STMI0=+00003	✓	✓	✓	✓
	QUICK STARTUP	OFF		VXX:QSUI1=+00000	QVX:QSUI1	QSUI1=+00000	✓	✓	✓	✓
		ON		VXX:QSUI1=+00001		QSUI1=+00001	✓	✓	✓	✓
	QUICK STARTUP-VALID PIRIOD	30MIN.		VXX:QSUI2=+00030	QVX:QSUI2	QSUI2=+00030	✓	✓	✓	✓
		60MIN.		VXX:QSUI2=+00060		QSUI2=+00060	✓	✓	✓	✓
		90MIN.		VXX:QSUI2=+00090		QSUI2=+00090	✓	✓	✓	✓
	SCHEDULE	OFF		VXX:SCHI0=+00000	QVX:SCHI0	SCHI0=+00000	✓	✓	✓	✓
		ON		VXX:SCHI0=+00001		SCHI0=+00001	✓	✓	✓	✓
	SCHEDLE-PROGRAM ASSIGN	OFF		VXX:SPGI*=+00000	QVX:SPGI*	SPGI*=+00000	✓	✓	✓	✓
		PROGRAM1		VXX:SPGI*=+00001		SPGI*=+00001	✓	✓	✓	✓
		PROGRAM2		VXX:SPGI*=+00002		SPGI*=+00002	✓	✓	✓	✓
		PROGRAM3		VXX:SPGI*=+00003		SPGI*=+00003	✓	✓	✓	✓
		PROGRAM4		VXX:SPGI*=+00004		SPGI*=+00004	✓	✓	✓	✓
		PROGRAM5		VXX:SPGI*=+00005		SPGI*=+00005	✓	✓	✓	✓
		PROGRAM6		VXX:SPGI*=+00006		SPGI*=+00006	✓	✓	✓	✓
		PROGRAM7		VXX:SPGI*=+00007		SPGI*=+00007	✓	✓	✓	✓
		* PARAMETER	SUN	VXX:SPGI0=+0000*	QVX:SPGI0	SPGI0=+0000*	✓	✓	✓	✓
			MON	VXX:SPGI1=+0000*	QVX:SPGI1	SPGI1=+0000*	✓	✓	✓	✓
			TUE	VXX:SPGI2=+0000*	QVX:SPGI2	SPGI2=+0000*	✓	✓	✓	✓
			WED	VXX:SPGI3=+0000*	QVX:SPGI3	SPGI3=+0000*	✓	✓	✓	✓
			THU	VXX:SPGI4=+0000*	QVX:SPGI4	SPGI4=+0000*	✓	✓	✓	✓
			FRI	VXX:SPGI5=+0000*	QVX:SPGI5	SPGI5=+0000*	✓	✓	✓	✓
			SAT	VXX:SPGI6=+0000*	QVX:SPGI6	SPGI6=+0000*	✓	✓	✓	✓
	SCHEDLE-COMMAND SETTING	COMMAND Del		VXX:SCCS*=**00****	QVX:SCCS*=**	SCCS*=**00****	✓	✓	✓	✓
		STANDBY		VXX:SCCS*=**10****		SCCS*=**10****	✓	✓	✓	✓
		POWER ON		VXX:SCCS*=**11****		SCCS*=**11****	✓	✓	✓	✓
		SHUTTER OPEN		VXX:SCCS*=**20****		SCCS*=**20****	✓	✓	✓	✓
		SHUTTER CLOSE		VXX:SCCS*=**21****		SCCS*=**21****	✓	✓	✓	✓
		RGB1 INPUT		VXX:SCCS*=**31****		SCCS*=**31****	✓	✓	✓	✓
		RGB2 INPUT		VXX:SCCS*=**32****		SCCS*=**32****	✓	✓	✓	✓
		VIDEO INPUT		VXX:SCCS*=**41****		SCCS*=**41****	✓	✓	✓	✓
		HDMI1 INPUT		VXX:SCCS*=**53****		SCCS*=**53****	✓	✓	✓	✓
		HDMI2 INPUT		VXX:SCCS*=**54****		SCCS*=**54****	✓	✓	✓	✓
		MEMORY VIEWER		VXX:SCCS*=**5A****		SCCS*=**5A****	✓	✓	✓	✓
		PANASONIC APPLICATION		VXX:SCCS*=**5B****		SCCS*=**5B****	✓	✓	✓	✓
		MIRRORING		VXX:SCCS*=**5C****		SCCS*=**5C****	✓	✓	✓	✓
		NORMAL		VXX:SCCS*=**70****		SCCS*=**70****	✓	✓	✓	✓
		ECO		VXX:SCCS*=**71****		SCCS*=**71****	✓	✓	✓	✓
		SILENT		VXX:SCCS*=**78****		SCCS*=**78****	✓	✓	✓	✓
		DIGITAL LINK		VXX:SCCS*=**B0****		SCCS*=**B0****	✓	✓	✓	✓
		INPUT 1		VXX:SCCS*=**B1****		SCCS*=**B1****	✓	✓	✓	✓
		INPUT 2		VXX:SCCS*=**B2****		SCCS*=**B2****	✓	✓	✓	✓
		INPUT 3		VXX:SCCS*=**B3****		SCCS*=**B3****	✓	✓	✓	✓
		INPUT 4		VXX:SCCS*=**B4****		SCCS*=**B4****	✓	✓	✓	✓
		INPUT 5		VXX:SCCS*=**B5****		SCCS*=**B5****	✓	✓	✓	✓
		INPUT 6		VXX:SCCS*=**B6****		SCCS*=**B6****	✓	✓	✓	✓
		INPUT 7		VXX:SCCS*=**B7****		SCCS*=**B7****	✓	✓	✓	✓
		INPUT 8		VXX:SCCS*=**B8****		SCCS*=**B8****	✓	✓	✓	✓
		INPUT 9		VXX:SCCS*=**B9****		SCCS*=**B9****	✓	✓	✓	✓
		INPUT 10		VXX:SCCS*=**BA****		SCCS*=**BA****	✓	✓	✓	✓
		AUDIO IN STANDBY OFF		VXX:SCCS*=**A0****		SCCS*=**A0****	✓	✓	✓	✓
		AUDIO IN STANDBY ON		VXX:SCCS*=**A1****		SCCS*=**A1****	✓	✓	✓	✓
		QUICK STARTUP OFF		VXX:SCCS*=**A2****		SCCS*=**A2****	✓	✓	✓	✓
		QUICK STARTUP ON		VXX:SCCS*=**A3****		SCCS*=**A3****	✓	✓	✓	✓
		AUDIO VOLUME	0	VXX:SCCS*=**C0****		SCCS*=**C0****	✓	✓	✓	✓
			63	VXX:SCCS*=**FF****		SCCS*=**FF****	✓	✓	✓	✓
		* PARAMETER1	PROGRAM1	VXX:SCCS1=********	QVX:SCCS1=**	SCCS1=********	✓	✓	✓	✓
			PROGRAM2	VXX:SCCS2=********	QVX:SCCS2=**	SCCS2=********	✓	✓	✓	✓
			PROGRAM3	VXX:SCCS3=********	QVX:SCCS3=**	SCCS3=********	✓	✓	✓	✓
			PROGRAM4	VXX:SCCS4=********	QVX:SCCS4=**	SCCS4=********	✓	✓	✓	✓
			PROGRAM5	VXX:SCCS5=********	QVX:SCCS5=**	SCCS5=********	✓	✓	✓	✓
			PROGRAM6	VXX:SCCS6=********	QVX:SCCS6=**	SCCS6=********	✓	✓	✓	✓
			PROGRAM7	VXX:SCCS7=********	QVX:SCCS7=**	SCCS7=********	✓	✓	✓	✓
		* PARAMETER2	COMMAND 1	VXX:SCCS*=01******	QVX:SCCS*=01	SCCS*=01******	✓	✓	✓	✓
			COMMAND 16	VXX:SCCS*=16******	QVX:SCCS*=16	SCCS*=16******	✓	✓	✓	✓
		* PARAMETER3	00:00	VXX:SCCS*=****0000		SCCS*=****0000	✓	✓	✓	✓
			23:59	VXX:SCCS*=****2359		SCCS*=****2359	✓	✓	✓	✓
	STARTUP INPUT SELECT	RGB1		VXX:SISS1=RG1	QVX:SISS1	SISS1=RG1	✓	✓	✓	✓
		RGB2		VXX:SISS1=RG2		SISS1=RG2	✓	✓	✓	✓
		VIDEO		VXX:SISS1=VID		SISS1=VID	✓	✓	✓	✓
		HDMI1		VXX:SISS1=HD1		SISS1=HD1	✓	✓	✓	✓
		HDMI2		VXX:SISS1=HD2		SISS1=HD2	✓	✓	✓	✓
		DIGITAL LINK		VXX:SISS1=DL1		SISS1=DL1	✓	✓	✓	✓
		MEMORY VIEWER		VXX:SISS1=MV1		SISS1=MV1	✓	✓	✓	✓
		PANASONIC APPLICATION		VXX:SISS1=PA1		SISS1=PA1	✓	✓	✓	✓
		MIRRORING		VXX:SISS1=MC1		SISS1=MC1	✓	✓	✓	✓
		LAST USED		VXX:SISS1=LSU		SISS1=LSU	✓	✓	✓	✓
	STARTUP INPUT SELECT (DIGITAL LINK)	LAST USED		VXX:SISI2=+00000	QVX:SISI2	SISI2=+00000	✓	✓	✓	✓
		INPUT1		VXX:SISI2=+00001		SISI2=+00001	✓	✓	✓	✓
		INPUT2		VXX:SISI2=+00002		SISI2=+00002	✓	✓	✓	✓
		INPUT3		VXX:SISI2=+00003		SISI2=+00003	✓	✓	✓	✓
		INPUT4		VXX:SISI2=+00004		SISI2=+00004	✓	✓	✓	✓
		INPUT5		VXX:SISI2=+00005		SISI2=+00005	✓	✓	✓	✓
		INPUT6		VXX:SISI2=+00006		SISI2=+00006	✓	✓	✓	✓
		INPUT7		VXX:SISI2=+00007		SISI2=+00007	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
PROJECTOR SETUP		INPUT8		VXX:SISI2=+00008		SISI2=+00008	✓	✓	✓	✓
		INPUT9		VXX:SISI2=+00009		SISI2=+00009	✓	✓	✓	✓
		INPIT10		VXX:SISI2=+00010		SISI2=+00010	✓	✓	✓	✓
	REMOTE2 - MODE	DEFAULT		VXX:RMPI0=+00000	QVX:RMPI0	RMPI0=+00000	✓	✓	✓	✓
		USER		VXX:RMPI0=+00001		RMPI0=+00001	✓	✓	✓	✓
		F/FW SERIES		VXX:RMPI0=+00003		RMPI0=+00003	✓	✓	✓	✓
	REMOTE2 - PIN2	NONE		VXX:RMPS1=P2<NONE	QVX:RMPS1=P2	RMPS1=P2<NONE	✓	✓	✓	✓
		POWER		VXX:RMPS1=P2<POWER		RMPS1=P2<POWER	✓	✓	✓	✓
	REMOTE2 - PIN3 - 7	* PARAMETER		VXX:RMPS1=P*<*****	QVX:RMPS1=P*		✓	✓	✓	✓
		* PARAMETER1	PIN3	VXX:RMPS1=P3<*****		RMPS1=P3<*****	✓	✓	✓	✓
			PIN4	VXX:RMPS1=P4<*****		RMPS1=P4<*****	✓	✓	✓	✓
			PIN5	VXX:RMPS1=P5<*****		RMPS1=P5<*****	✓	✓	✓	✓
			PIN6	VXX:RMPS1=P6<*****		RMPS1=P6<*****	✓	✓	✓	✓
			PIN7	VXX:RMPS1=P7<*****		RMPS1=P7<*****	✓	✓	✓	✓
		* PARAMETER2	NONE	VXX:RMPS1=P*<NONE		RMPS1=P*<NONE	✓	✓	✓	✓
			RGB1	VXX:RMPS1=P*<RGB1		RMPS1=P*<RGB1	✓	✓	✓	✓
			RGB2	VXX:RMPS1=P*<RGB2		RMPS1=P*<RGB2	✓	✓	✓	✓
			VIDEO	VXX:RMPS1=P*<VIDEO		RMPS1=P*<VIDEO	✓	✓	✓	✓
			HDMI	VXX:RMPS1=P*<HDMI		RMPS1=P*<HDMI	✓	✓	✓	✓
			HDMI1	VXX:RMPS1=P*<HDMI1		RMPS1=P*<HDMI1	✓	✓	✓	✓
			HDMI2	VXX:RMPS1=P*<HDMI2		RMPS1=P*<HDMI2	✓	✓	✓	✓
			DIGITAL LINK	VXX:RMPS1=P*<DLINK		RMPS1=P*<DLINK	✓	✓	✓	✓
			MEMORY VIEWER	VXX:RMPS1=P*<MV1		RMPS1=P*<MV1	✓	✓	✓	✓
			Panasonic APPLICATION	VXX:RMPS1=P*<PA1		RMPS1=P*<PA1	✓	✓	✓	✓
			MIRRORING	VXX:RMPS1=P*<MC1		RMPS1=P*<MC1	✓	✓	✓	✓
	REMOTE2 - PIN8	NONE	NONE	VXX:RMPS1=P8<NONE	QVX:RMPS1=P8	RMPS1=P8<NONE	✓	✓	✓	✓
		SHUTTER	SHUTTER	VXX:RMPS1=P8<SHUTTER		RMPS1=P8<SHUTTER	✓	✓	✓	✓
	FUNCTION BUTTON	DISABLE		OFC:0	QFC	0	✓	✓	✓	✓
		SYSTEM SELECTOR		OFC:1		1	✓	✓	✓	✓
		SYSTEM DAYLIGHT VIEW		OFC:2		2	✓	✓	✓	✓
		SUB MEMORY		OFC:3		3	✓	✓	✓	✓
	DATE AND TIME-DATE SETTING	Year: yyyy		TSD:201506151	QGD	201506161	✓	✓	✓	✓
		Month: mm		TSD:*yyyymmddw*		*yyyymmddw*	✓	✓	✓	✓
		Date: dd					✓	✓	✓	✓
		Day:w(1~7:Mon~Sun)					✓	✓	✓	✓
	DATE AND TIME-TIME SETTING	Hour: hh		TST:154503	QGT	154503	✓	✓	✓	✓
		Minute: mm		TST:*hhmmss*		*hhmmss*	✓	✓	✓	✓
		Second: ss					✓	✓	✓	✓
	DATE AND TIME-NTP SYNCHRONIZATION	OFF		VXX:NTPI0=+00000	QVX:NTPI0	NTPI0=+00000	✓	✓	✓	✓
		ON		VXX:NTPI0=+00001		NTPI0=+00001	✓	✓	✓	✓
	LENS CALIBRATION	EXECUTE (ALL)		VXX:LNSI0=+00001			✓	✓	✓	✓
	INITIALIZE-ALL USER DATA	USER INITILIZE		VXX:RSTS1=0*password*			✓	✓	✓	✓
		USER RESTORE		VXX:RSTS1=1*password*			✓	✓	✓	✓
	INITIAL START UP	STANDBY		OPY:0	QPY	0	✓	✓	✓	✓
		ON		OPY:1		1	✓	✓	✓	✓
		LAST MEMORY		OPY:2		2	✓	✓	✓	✓
	EMULATE	DEFAULT		VXX:EMUI0=+00001	QVX:EMUI0	EMUI0=+00001	✓	✓	✓	✓
		D3500		VXX:EMUI0=+00002		EMUI0=+00002	✓	✓	✓	✓
		D4000		VXX:EMUI0=+00003		EMUI0=+00003	✓	✓	✓	✓
		D/W5k SERIES		VXX:EMUI0=+00004		EMUI0=+00004	✓	✓	✓	✓
		D/W/Z6k SERIES		VXX:EMUI0=+00005		EMUI0=+00005	✓	✓	✓	✓
		L730		VXX:EMUI0=+00006		EMUI0=+00006	✓	✓	✓	✓
		L780		VXX:EMUI0=+00007		EMUI0=+00007	✓	✓	✓	✓
		L735		VXX:EMUI0=+00008		EMUI0=+00008	✓	✓	✓	✓
		L785		VXX:EMUI0=+00009		EMUI0=+00009	✓	✓	✓	✓
		LB/W SERIES		VXX:EMUI0=+00010		EMUI0=+00010	✓	✓	✓	✓
		F/W SERIES		VXX:EMUI0=+00011		EMUI0=+00011	✓	✓	✓	✓
		LZ370		VXX:EMUI0=+00012		EMUI0=+00012	✓	✓	✓	✓
		VX500 SERIES		VXX:EMUI0=+00013		EMUI0=+00013	✓	✓	✓	✓
		EZ570 SERIES		VXX:EMUI0=+00014		EMUI0=+00014	✓	✓	✓	✓
		VW431D SERIES		VXX:EMUI0=+00015		EMUI0=+00015	✓	✓	✓	✓
	AUDIO SETTING-VOLUME	0		AVL:000	QAV	000	✓	✓	✓	✓
		63		AVL:063		063	✓	✓	✓	✓
	AUDIO SETTING-BALANCE	-16		ABL:-16	QBL	-16	✓	✓	✓	✓
		16		ABL:016		16	✓	✓	✓	✓
	AUDIO SETTING-IN STANDBY MODE	OFF		VXX:ASBI0=+00000	QVX:ASBI0	ASBI0=+00000	✓	✓	✓	✓
		ON		VXX:ASBI0=+00001		ASBI0=+00001	✓	✓	✓	✓
	AUDIO SETTING-IN SHUTTER MODE	OFF		VXX:ASHI1=+00000	QVX:ASHI1	ASHI1=+00000	✓	✓	✓	✓
		ON		VXX:ASHI1=+00001		ASHI1=+00001	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-COMPUTER1	AUDIO IN 1		VXX:AINI0=+00000	QVX:AINI0	AINI0=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI0=+00001		AINI0=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI0=+00002		AINI0=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-COMPUTER2	AUDIO IN 1		VXX:AINI1=+00000	QVX:AINI1	AINI1=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI1=+00001		AINI1=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI1=+00002		AINI1=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-HDMI1	HDMI1 AUDIO IN		VXX:AINI3=+00003	QVX:AINI3	AINI3=+00003	✓	✓	✓	✓
		AUDIO IN 1		VXX:AINI3=+00000		AINI3=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI3=+00001		AINI3=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI3=+00002		AINI3=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-VIDEO	AUDIO IN 1		VXX:AINI4=+00000	QVX:AINI4	AINI4=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI4=+00001		AINI4=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI4=+00002		AINI4=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-NETWORK	NETWORK/USB AUDIO IN		VXX:AINI6=+00004	QVX:AINI6	AINI6=+00004	✓	✓	✓	✓
		AUDIO IN 1		VXX:AINI6=+00000		AINI6=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI6=+00001		AINI6=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI6=+00002		AINI6=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-HDMI2	HDMI2 AUDIO IN		VXX:AINI7=+00003	QVX:AINI7	AINI7=+00003	✓	✓	✓	✓
		AUDIO IN 1		VXX:AINI7=+00000		AINI7=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI7=+00001		AINI7=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI7=+00002		AINI7=+00002	✓	✓	✓	✓
	AUDIO SETTING-AUDIO IN SELECT-DIGITAL LINK	DIGITAL LINK ADUIO IN		VXX:AINI8=+00005	QVX:AINI8	AINI8=+00005	✓	✓	✓	✓
		AUDIO IN 1		VXX:AINI8=+00000		AINI8=+00000	✓	✓	✓	✓
		AUDIO IN 2		VXX:AINI8=+00001		AINI8=+00001	✓	✓	✓	✓
		AUDIO IN 3		VXX:AINI8=+00002		AINI8=+00002	✓	✓	✓	✓
	FILTER COUNTER-TIMER	OFF		VXX:FCTI1=+00000	QVX:FCTI1	FCTI1=+00000	✓	✓	✓	✓
		1000H		VXX:FCTI1=+01000		FCTI1=+01000	✓	✓	✓	✓
		2000H		VXX:FCTI1=+02000		FCTI1=+02000	✓	✓	✓	✓
		3000H		VXX:FCTI1=+03000		FCTI1=+03000	✓	✓	✓	✓
		4000H		VXX:FCTI1=+04000		FCTI1=+04000	✓	✓	✓	✓
		5000H		VXX:FCTI1=+05000		FCTI1=+05000	✓	✓	✓	✓
		6000H		VXX:FCTI1=+06000		FCTI1=+06000	✓	✓	✓	✓
		7000H		VXX:FCTI1=+07000		FCTI1=+07000	✓	✓	✓	✓
		8000H		VXX:FCTI1=+08000		FCTI1=+08000	✓	✓	✓	✓
		9000H		VXX:FCTI1=+09000		FCTI1=+09000	✓	✓	✓	✓
		10000H		VXX:FCTI1=+10000		FCTI1=+10000	✓	✓	✓	✓
		11000H		VXX:FCTI1=+11000		FCTI1=+11000	✓	✓	✓	✓
		12000H		VXX:FCTI1=+12000		FCTI1=+12000	✓	✓	✓	✓
		13000H		VXX:FCTI1=+13000		FCTI1=+13000	✓	✓	✓	✓
		14000H		VXX:FCTI1=+14000		FCTI1=+14000	✓	✓	✓	✓
		15000H		VXX:FCTI1=+15000		FCTI1=+15000	✓	✓	✓	✓
		15000H		VXX:FCTI1=+16000		FCTI1=+16000	✓	✓	✓	✓
		15000H		VXX:FCTI1=+17000		FCTI1=+17000	✓	✓	✓	✓
		15000H		VXX:FCTI1=+18000		FCTI1=+18000	✓	✓	✓	✓
		15000H		VXX:FCTI1=+19000		FCTI1=+19000	✓	✓	✓	✓
		16000H		VXX:FCTI1=+20000		FCTI1=+20000	✓	✓	✓	✓
	FILTER COUNTER-RESET			VXX:FCTI2=+00000			✓	✓	✓	✓
	MODEL NAME	*MODEL NAME*			QID	*MODELNAME*	✓	✓	✓	✓
	SERIAL NUMBER	SW0101234			QSN	*SW0101234*	✓	✓	✓	✓
	PROJECTOR RUNTIME	7864320H			QVX:RTMS1	RTMS1=7864320	✓	✓	✓	✓
	LAMP1(LIGHT1) RUNTIME	9999H			Q$L:1	9999	✓	✓	✓	✓
	LIGHT1 RUNTIME	7864320H			QVX:LRTS3=00	LRTS3=00:7864320	✓	✓	✓	✓
	LIGHT STATUS	ALL OFF			QLS	0	✓	✓	✓	✓
		1:ON, 2:OFF				1	✓	✓	✓	✓
	LAMP(LIGHT) CONTROL STATUS	LAMP OFF			Q$S	0	✓	✓	✓	✓
		In turning ON				1	✓	✓	✓	✓
		LAMP ON				2	✓	✓	✓	✓
		LAMP Cooling				3	✓	✓	✓	✓
	AIR FILTER MODEL NUMBER	*FILTER MODELNAME*			QVX:FMNS0	FMNS0=*FILTERMODELNO*	✓	✓	✓	✓
	AIR FILTER TYPE	NORMAL		MFS:3	QFI:2	0	✓	✓	✓	✓
		SPECIAL		MFS:4		1	✓	✓	✓	✓
	FILTER COUNTER	99999H			QFI:0	99999	✓	✓	✓	✓
	MAC ADDRESS	AB0102030405			QMA	*AB0102030405*	✓	✓	✓	✓
	MAIN FIRMWARE VERSION	V1.00.01			QVX:SVRS0	SVRS0=1.00.01	✓	✓	✓	✓
	NETWORK FIRMWARE VERSION	V1.00			QVX:SVRS1	SVRS1=1.00	✓	✓	✓	✓
	SUB FIRMWARE VERSION	V1.00.01			QVX:SVRS2	SVRS2=1.00.01	✓	✓	✓	✓

				CONTROL	QUERY		MZ770 SERIES		MZ670 SERIES	
CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	COMMANDS/CALL BACK	COMMANDS	CALL BACK	MZ770 SMZ77C	MW730 SMW73C	MZ670 MZ570 SMZ66C	MW630 MW530
	INPUT SIGNAL NAME	CHANNEL1 (MAIN CH)			QVX:NSGS1	NSGS1=*****.....	✓	✓	✓	✓
	DC OUT	OFF		VXX:DCOI1=+00000	QVX:DCOI1	DCOI1=+00000	✓	✓	✓	✓
		ON		VXX:DCOI1=+00001		DCOI1=+00001	✓	✓	✓	✓
	TEMPERATURE (INTAKE)	0030/0080			QTM:0	0030/0080	✓	✓	✓	✓
	TEMPERATURE (EXHAUST AIR)	0030/0080			QTM:1	0030/0080	✓	✓	✓	✓
	TEMPERATURE (OPTICS MODULE)	0030/0080			QTM:2	0030/0080	✓	✓	✓	✓
	TEMPERATURE (LIGHT1 / LIGHT1-	0030/0080			QTM:11	0030/0080	✓	✓	✓	✓
	TEMPERATURE (LIGHT2 / LIGHT1-	0030/0080			QTM:12	0030/0080	✓	✓	✓	✓
	LightID MODE	OFF		LID:MOD0	QLI:MOD	QLI:MOD0	✓	✓	✓	✓
		EXTERNAL CONTROL		LID:MOD1		QLI:MOD1	✓	✓	✓	✓
		INTERNAL ID		LID:MOD2		QLI:MOD2	✓	✓	✓	✓
	LAN data Cloning Write protect	OFF		LCL:WRP0	QCL:WRP	QCL:WRP0	✓	✓	✓	✓
		ON		LCL:WRP1		QCL:WRP1	✓	✓	✓	✓
TEST PATTERN	TEST PATTERN	Off		OTS:00	QTS	00	✓	✓	✓	✓
		White		OTS:01		01	✓	✓	✓	✓
		Black		OTS:02		02	✓	✓	✓	✓
		Window		OTS:05		05	✓	✓	✓	✓
		Reversed Window		OTS:06		06	✓	✓	✓	✓
		Cross Hatch		OTS:07		07	✓	✓	✓	✓
		Color Bar V		OTS:08		08	✓	✓	✓	✓
		Convergence		OTS:11		11	✓	✓	✓	✓
		Color Bar Side		OTS:51		51	✓	✓	✓	✓
		16:9/4:3		OTS:59		59	✓	✓	✓	✓
		Gradation 3		OTS:62		62	✓	✓	✓	✓
		Gradation 4		OTS:63		63	✓	✓	✓	✓
SIGNAL LIST	SIGNAL LIST-REGISTRATION			OEM			✓	✓	✓	✓
	SIGNAL LIST-DELETE	A1		ODM:A1			✓	✓	✓	✓
		A2		ODM:A2			✓	✓	✓	✓
		A7		ODM:A7			✓	✓	✓	✓
		A8		ODM:A8			✓	✓	✓	✓
		L1		ODM:L1			✓	✓	✓	✓
		L2		ODM:L2			✓	✓	✓	✓
		L7		ODM:L7			✓	✓	✓	✓
		L8		ODM:L8			✓	✓	✓	✓
	SUB MEMORY LIST-CHANGEOVER	01		OCS:01			✓	✓	✓	✓
		96		OCS:96			✓	✓	✓	✓
	SUB MEMORY LIST-CHANGEOVER (EXTENDED)	01		OCS:01-01			✓	✓	✓	✓
		96		OCS:95-96			✓	✓	✓	✓
	SUB MEMORY LIST-REGISTRATION			OES			✓	✓	✓	✓
	SUB MEMORY LIST-DELETE	01		ODS:01-01			✓	✓	✓	✓
		96		ODS:95-96			✓	✓	✓	✓
	SUB MEMORY USAGE STATE	01			QSB	01	✓	✓	✓	✓
		96				96	✓	✓	✓	✓
SECURITY	SECURITY SETTING	OFF			QVX:SPWI1	SPWI1=+00000	✓	✓	✓	✓
		ON				SPWI1=+00001	✓	✓	✓	✓
NETWORK	WIRELESS LAN	OFF(DISABLE)		ONS:0	QVX:WLSI1	WLSI1=+00000	✓	✓	✓	✓
		USER1		ONS:5		WLSI1=+00005	✓	✓	✓	✓
		M-DIRECT		ONS:12		WLSI1=+00012	✓	✓	✓	✓
		SIMPLE		ONS:13		WLSI1=+00013	✓	✓	✓	✓
	DIGITAL LINK MODE	AUTO		VXX:DKMI1=+00001	QVX:DKMI1	DKMI1=+00001	✓	✓	✓	✓
		DIGITAL LINK		VXX:DKMI1=+00002		DKMI1=+00002	✓	✓	✓	✓
		ETHERNET		VXX:DKMI1=+00003		DKMI1=+00003	✓	✓	✓	✓
		LONG REACH MODE		VXX:DKMI1=+00004		DKMI1=+00004	✓	✓	✓	✓
	DIGITAL LINK-DUPLEX(Ethernet)	Auto negotiation		VXX:DKDI1=+00000	QVX:DKDI1	DKDI1=+00000	✓	✓	✓	✓
		100BaseTX-Full		VXX:DKDI1=+00001		DKDI1=+00001	✓	✓	✓	✓
		100BaseTX-Half		VXX:DKDI1=+00002		DKDI1=+00002	✓	✓	✓	✓
	DIGITAL LINK-DUPLEX(DIGITAL LINK)	Auto negotiation		VXX:DKDI2=+00000	QVX:DKDI2	DKDI2=+00000	✓	✓	✓	✓
		100BaseTX-Full		VXX:DKDI2=+00001		DKDI2=+00001	✓	✓	✓	✓
		100BaseTX-Half		VXX:DKDI2=+00002		DKDI2=+00002	✓	✓	✓	✓
	DIGITAL LINK STATUS-LINK	NO LINK			QVX:DKSI1	DKSI1=+00000	✓	✓	✓	✓
		DIGITAL LINK				DKSI1=+00001	✓	✓	✓	✓
		LPM				DKSI1=+00002	✓	✓	✓	✓
		ETHERNET				DKSI1=+00003	✓	✓	✓	✓
	DIGITAL LINK STATUS-HDCP STATUS	NO SIGNAL			QVX:DKSI2	DKSI2=+00000	✓	✓	✓	✓
		OFF				DKSI2=+00001	✓	✓	✓	✓
		ON				DKSI2=+00002	✓	✓	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MIN)	-255			QVX:DKSI3	DKSI3=-00255	✓	✓	✓	✓
		0				DKSI3=+00000	✓	✓	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	-255			QVX:DKSI4	DKSI4=-00255	✓	✓	✓	✓
		0				DKSI4=+00000	✓	✓	✓	✓
	DIGITAL LINK INPUT CH LIST	*HD1:HDMI1,HD2:HDMI2…*			QVX:DL1S1	DL1S1=HD1:HDMI1,****:***	✓	✓	✓	✓
	PROJECTOR NAME SETTING	*PROJECTOR1*		VXX:NCGS8=*PROJECTOR1*	QVX:NCGS8	NCGS8=*PROJECTOR1*	✓	✓	✓	✓
MEMORY VIEWER	VIEW	THUMBNAIL		VXX:MEMI1=+00000	QVX:MEMI1	MEMI1=+00000	✓	✓	✓	✓
		LIST		VXX:MEMI1=+00001		MEMI1=+00001	✓	✓	✓	✓
	SORT	NAME		VXX:MEMI2=+00000	QVX:MEMI2	MEMI2=+00000	✓	✓	✓	✓
		TYPE		VXX:MEMI2=+00001		MEMI2=+00001	✓	✓	✓	✓
		TIME		VXX:MEMI2=+00002		MEMI2=+00002	✓	✓	✓	✓
	AUTOPLAY	OFF		VXX:MEMI3=+00000	QVX:MEMI3	MEMI3=+00000	✓	✓	✓	✓
		ON		VXX:MEMI3=+00001		MEMI3=+00001	✓	✓	✓	✓
		SCENARIO		VXX:MEMI3=+00100		MEMI3=+00100	✓	✓	✓	✓
	INTERVAL	5s		VXX:MEMI4=+00005	QVX:MEMI4	MEMI4=+00005	✓	✓	✓	✓
		10s		VXX:MEMI4=+00010		MEMI4=+00010	✓	✓	✓	✓
		15s		VXX:MEMI4=+00015		MEMI4=+00015	✓	✓	✓	✓
		30s		VXX:MEMI4=+00030		MEMI4=+00030	✓	✓	✓	✓
		60s		VXX:MEMI4=+00060		MEMI4=+00060	✓	✓	✓	✓
		120s		VXX:MEMI4=+00120		MEMI4=+00120	✓	✓	✓	✓
	EFFECT	OFF		VXX:MEMI5=+00000	QVX:MEMI5	MEMI5=+00000	✓	✓	✓	✓
		RANDOM		VXX:MEMI5=+00001		MEMI5=+00001	✓	✓	✓	✓
		WIPE LEFT		VXX:MEMI5=+00002		MEMI5=+00002	✓	✓	✓	✓
		WIPE RIGHT		VXX:MEMI5=+00003		MEMI5=+00003	✓	✓	✓	✓
		WIPE DOWN		VXX:MEMI5=+00004		MEMI5=+00004	✓	✓	✓	✓
		SPRIT		VXX:MEMI5=+00005		MEMI5=+00005	✓	✓	✓	✓
		ZOOM OUT		VXX:MEMI5=+00006		MEMI5=+00006	✓	✓	✓	✓
		FADE		VXX:MEMI5=+00007		MEMI5=+00007	✓	✓	✓	✓
		BLIND		VXX:MEMI5=+00008		MEMI5=+00008	✓	✓	✓	✓
		CHECKER WIPE		VXX:MEMI5=+00009		MEMI5=+00009	✓	✓	✓	✓
		SLIDE IN		VXX:MEMI5=+00010		MEMI5=+00010	✓	✓	✓	✓
		SLIDE OUT		VXX:MEMI5=+00011		MEMI5=+00011	✓	✓	✓	✓
	GUIDE	OFF		VXX:MEMI6=+00000	QVX:MEMI6	MEMI6=+00000	✓	✓	✓	✓
		ON		VXX:MEMI6=+00001		MEMI6=+00001	✓	✓	✓	✓

Note: The commands or parameters with "*" shows avalable commands or parameters for the projector which has been activated by the Upgrade Kit.